


# PennEngineering®

CE



**OPERATION AND MAINTENANCE MANUAL FOR PEMSERTER®  
PAT2400-E Hardware insertion machine**

# **OPERATION AND MAINTENANCE MANUAL**

**Hardware Insertion Machine**

**MODEL: PAT2400-E**

**SERIAL NUMBER: T24E240004**

**PennEngineering®**

**99 Chenfeng Middle Road Kunshan**

**215300 Jiangsu P. R. China**

**+86(512)5726-9310 [www.pemnet.com](http://www.pemnet.com)**

**PRODUCED IN CHINA BY PEM (CHINA) Co., Ltd**

Document Part Number: MDSMDS183230011

Revision A

DCR: KS24-0XXX

Date: 16-July-2024

## **Preface**

Copyright 2024 by PennEngineering®, Inc. All rights reserved.

No part of this documentation may be reproduced, copied or transmitted in any form, or by any electronic, digital or other means, without permission in writing from PennEngineering®, Inc. (referred to herein as the “Company”). This includes photocopying and information storage and retrieval systems. The material in this documentation is subject to change without notice.

PLEASE READ THESE TERMS AND CONDITIONS CAREFULLY BEFORE USING THE SOFTWARE INCLUDED WITH THE EQUIPMENT. BY USING THE SOFTWARE ACCOMPANYING THE EQUIPMENT YOU AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF THIS LICENSE.

All software furnished with the equipment is on a licensed basis. The Company grants to the user a non-transferable and non-exclusive license to use such software in object code only and solely in connection with the use of the equipment. Such license may not be assigned, sublicensed, or otherwise transferred by the user apart from the equipment. No right to copy a licensed program in whole or in part is granted. Title to the software and documentation shall remain with the Company. The user shall not modify, merge, or incorporate any form or portion of a licensed program with other program material, create a derivative work from a licensed program, or use a licensed program in a network. The user agrees to maintain the Company’s copyright notice on the licensed programs delivered with the equipment. The user agrees not to decompile, disassemble, decode, or reverse engineer any licensed program delivered with the equipment, or any portion thereof.

**LIMITED WARRANTY:** The Company warrants only that the software will perform in accordance with the documentation accompanying the equipment during the equipment warranty period. The Company does not warrant that the software is error free. The user’s exclusive remedy and the Company’s sole liability for defects in the software as to which the Company is notified during the equipment warranty period is to repair or replace the software at the Company’s option. This limited warranty does not apply if the software has been altered, the user has failed to operate the software in accordance with this documentation, or the software has been subject to abnormal physical or electrical stress, misuse, negligence or accident.

EXCEPT FOR THE EXPRESS WARRANTY SET FORTH ABOVE, THE SOFTWARE IS PROVIDED “AS IS” WITH ALL FAULTS. THE COMPANY DISCLAIMS ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THE EQUIPMENT, THE SOFTWARE OR ANY PART OF THIS DOCUMENTATION, EVEN IF THE COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

## CONTENTS

SECTION 1 INTRODUCTION.....	1
SECTION 2 MAJOR COMPONENTS OF HARDWARE INSERTION MACHINE.....	8
SECTION 3 SAFETY SYSTEM OPERATION.....	19
SECTION 4 INSTALLATION OF HARDWARE INSERTION MACHINE .....	24
SECTION 5 GENERAL FUNCTION DESCRIPTIONS.....	28
SECTION 6 TOUCH-SCREEN CONTROLS .....	30
SECTION 7 PNEUMATIC SYSTEM.....	52
SECTION 8 ELECTRICAL SYSTEM.....	54
SECTION 9 MAINTENANCE .....	56
SECTION 10 TROUBLESHOOTING .....	62
SECTION 11 SPARE PARTS .....	65
Appendix Electrical Schematic.....	68





# Read Manual Before Operating Machine!

## SECTION 1 INTRODUCTION

### Use:

- This equipment is used for the riveting of some PEM screws, nuts and studs fastening products.
- This equipment is composed of a touch screen, a safety punch, a feeding system, a tooling fixture and an XYZ high speed mobile platform. The product to be riveted can be sent to the tooling fixture through the feeding system as required, and the product to be riveted can be riveted through the safety punch Press to the workpiece to complete the riveting process.
- According to different processes and workpieces, the tooling fixtures corresponding to different products can be replaced automatically to achieve the purpose of riveting and connecting different products.


### Features:

- Unique precise pressure riveting force and energy-saving riveting power consumption.
- Computer control system with touch screen interface.
- The riveting algorithm is intelligent, can display the pressure-position curve, and has the function of parameter memory and curve memory.
- Provide simple and precise control for operators. The design of the machine setting, operation, maintenance and fault diagnosis is simple and easy to use.

### Specifications:

- |                                 |  |
|---------------------------------|--|
| • Riveting Force                | 8~80kN (1798.5-17984lbs)   |
| • Control System                | Servo motor system   |
| • Repeatability                 | $\pm 0.5\%$ pressure accuracy<br>$\pm 0.02\text{mm}$ position accuracy                           |
| • Air requirements              | 6~7bar<br>$\Phi 12$ mm dia. minimum line flow  |
| • Depth                         | 3100mm   |
| • Width                         | 6600mm   |
| • Hight                         | 2300mm   |
| • Weight                        | 6200kg   |
| • Electrical                    | AC400V ( +/- AC 23 V ) , 50Hz  |
| • Short-Circuit Rating          | 5kA  |
| • Air Consumption               | approx. 2 liters/sec air at 1 Atm (15 Scfm) 6 insertions per minute                              |
| • Electrical Power Consumption  | 13.5kW   |
| • Ambient Temperature           | 5°C~40°C (41°F ~ 104°F)  |
| • Transport/Storage Temperature | -13°F to +130°F (-25°C to +55°C) and for short periods not to exceed 24 hours up to 160°F (70°C) |
| • Ambient Humidity              | 30% ~ 95% (Not reflective of inlet air)  |
| • Installation Altitude         | Max 1000m  |

- Installation requires horizontal installation on load-bearing ground
- EMC requires Do not allow a lot of electromagnetic interference around
- Light requires adequate illumination at the operating points and areas



**FIGURE 1-1**

**Dimensions of PAT2400-E Hardware insertion machine**

## **SAFETY**

The Rivet Installation Machine PAT12000-E was designed to conform to applicable ISO, ANSI, OSHA, CEN and CSA safety standards.

The Rivet Installation Machine PAT12000-E is compliant to applicable European Union (EU) directives and bears the CE Mark.

The Rivet Installation Machine PAT12000-E conforms to the essential requirements of the following directives:

Machinery Directive: 2006/42/EC

Electromagnetic Compatibility (EMC) Directive: 2014/30/EU

Low Voltage Directive: 2014/35/EU



### **MEASURES TO PREVENT MISOPERATION**

- The equipment shall be provided with a permanent, clear and easily identifiable mark or signage. The signs or signs shall have the main characteristics required for safe use of equipment, such as rated parameters, connection mode, grounding mark, danger mark, special operation method and operation conditions, etc.
- Electrical control circuit with emergency stop button specified in safety requirements to prevent the occurrence of misoperation. At the same time, the device is equipped with interlock or limit protection device, safety grating, etc.
- Through the above safety device, if there is any wrong operation, the equipment will stop running in an emergency and send an alarm message the equipment can operate normally only after the warning information is processed.
- Riveting nuts approved by PEM shall be used in this equipment, and riveting workpiece on this equipment shall also be approved by PEM. PEM shall not be liable for any operation accident or loss caused using rivet and rivet pressure parts not approved by PEM.

Please read and follow the safety precautions listed as below.



### **SAFETY PRECAUTIONS**






- ◆ Always use safety goggles when operating or maintaining the rivet installation machine.
- ◆ Ear Protection is recommended.
- ◆ Always shut off the electrical power and remove the power cord before servicing the Hardware insertion machine.
- ◆ Before using the Hardware insertion machine, make sure that a shutoff device has been fitted on the air supply line and the location is easily accessible, so that the air supply to the rivet installation machine can be shut off in an emergency. Make sure that surge protection is installed in the electrical supply to the rivet installation machine.
- ◆ Check the air hose and fittings regularly for wear.
- ◆ Use only approved parts for maintenance and repairs.
- ◆ Do not use chipped, cracked or damaged accessories and tools.
- ◆ Attach airline securely.
- ◆ Keep body parts away from moving parts.
- ◆ Never wear jewelry, loose clothing or anything that could get caught in moving parts.
- ◆ If a new user is operating the pull riveting machine, be sure these instructions are readily available.

- ◆ Do not use the Hardware insertion machine in any way, other than for its intended purposes.
- ◆ Do not modify the Hardware insertion machine in any way.
- ◆ Fasteners are blown at a high velocity. Tubing must always be secured before machine is operated. Check integrity of tubing before use.
- ◆ Non-professionals are prohibited from disassembling this equipment.
- ◆ All personnel operating this equipment must be trained and qualified before they can take up the post of operation.
- ◆ All personnel operating this equipment must be trained and qualified before they can take up the post of operation.



**WARNING:** Immediately upon receipt of your hardware insertion machine, establish a “Maintenance Code” for your supervisor/maintenance personnel only, as it is possible, however difficult, to operate the rivet installation machine without the standard safeguards in place in the Maintenance Mode. Only trained personnel should use the Maintenance Mode. PennEngineering is not responsible for improper maintenance mode procedures, which result in a loss of operation of the press or operator safety.

---

Label	Definition
	General Warning Label – There are items that require attention. These are specified in the operator’s manual.
	Eye Protection Label – Eye protection must be worn when operating the press.
	Ear Protection Label – Ear protection must be worn when operating the pull riveting machine.
	Fastener Mandrel Point Label – Keep hands away from area.
	Electrical Shock/Electrocution Warning Label –Electrical shock hazard. Do not touch

## **WARRANTY**

PennEngineering® warrants that this product, when correctly used according to directions and under normal operating conditions, will be free from defects in material and workmanship for a period of one (1) year from the date of purchase.

This warranty shall not apply to any product which has been altered, changed or repaired, normal maintenance excluded, except as authorized by PennEngineering®. This warranty shall not apply to any product that has been subject to misuse, negligence or accident.

The purchaser's exclusive and sole remedy shall be limited to repair, modification or replacement at the discretion of PennEngineering®. In no event shall PennEngineering® be liable for the cost of any indirect or consequential damage. In no case shall PennEngineering® liability exceed the purchase price of the product.

This warranty is exclusive and in lieu of all other warranties. No oral or written information by PennEngineering®, its employees, representatives, distributors or agents shall increase the scope of the above warranty or create any new warranty.

Should any questions or problems arise concerning your rivet installation machine, contact the PennEngineering® Service Department. Toll-free telephone number +86(512) 5726-9310.

Set-up, Training and Repair Service is available to you if you own your rivet installation machine. Free telephone instruction and Service is available for the lifetime of your rivet installation machine by calling the PennEngineering® Service Department.

## SECTION 2

# MAJOR COMPONENTS OF HARDWARE INSERTION MACHINE

### Identify the main components of the Hardware Insertion Machine.

This chapter introduces users to some of the main components of the Hardware Insertion Machine.

#### Main Frame

The frame is the structure of the hardware insertion machine. The main part of the frame consists of a solid steel structure with welded components forming the foundation, and other supporting parts. All components are directly or insightly installed on the frame.

#### Electric cylinder

The riveting force of the hardware insertion machine is applied by the electric cylinder, which is directly installed on the frame. The electric cylinder is equipped with a pressure sensor to determine whether the electric cylinder has reached the set pressure during the riveting process. The end of the piston rod of the electric cylinder relates to a safety punch assembly, which will be described in Chapter 3.W

#### XYZ high speed mobile platform

The three-axis platform drives the product to achieve precise movement in the three directions of X, Y, and Z. The XYZ platform mainly includes the X-axis moving part, the Y-axis moving part, and the Z-axis moving part. The movement of each axis is achieved by the servo motor driving the linear module, and there are high-precision guide rails to assist in guiding, with high repeatability and positioning accuracy.

#### Operator control

Except for the foot switch and the power switch on the electric cabinet, the operator's main operations are on the control panel on the **PMCS**. These control components include a touch screen, an emergency stop button, a power on button, and a spring reset button.

- **PMCS (PennEngineering machine control system)** -This is the main interface of the hardware insertion machine control system (Programmable Automation Controller (PAC)). The screen is used for system operation, control, parameter setting and automatic feeding adjustment and configuration, user feedback and fault diagnosis. The screen can display text and graphic information and enables the operator to make selections by touching the buttons on different parts of the screen. The program has set the touch screen to automatically enter the screen saver mode when it is idle every 10 minutes and clear the content displayed on the screen. To resume the operation of the screen, just press any key on the keyboard. In Chapter 6 of this manual, the screen display in various situations is explained in detail.
- **Emergency stop button**-Press this button to disconnect the power supply to the quick exhaust/air supply valve (see the air supply input system on page 8). When the pressure is exhausted, all



pneumatic actions are stopped. In an emergency stop condition, all outputs are shut down. The control system remains online and detects the emergency stop signal.

- **Power ON/OFF knob switch**- This knob switch can be used to turn on/off the power to the press control system, if the press power is on, then the green light of the electrical cabinet is on. If the power is cut off, it will also cut off the power of all moving elements including the quick exhaust/air supply valve.
- **RESET button**- Initializes the press, including applying pressure to the press and moving the ram to its retracted “home” position.
- **Foot switch**-The foot switch is a switch used by the operator to control the working cycle of the riveting machine. It frees the hands of the operator and can be used for the operation of the workpiece.

### **Electrical cabinet**

Including different types of electrical components and power distribution terminals. The power switch and the foot switch are connected with the electrical cabinet. Electrical cabinet door latch with a key, is an electrical switch cabinet side. The electrical switch must be turned on (ON) before the riveting machine can be started. Once this switch is turned off, all power to the riveting machine is cut off. The plug of the power cord is inserted next to the switch. By unplugging the power cord, all power supplies of the riveting machine can be shut off during maintenance.

### **Vibration feeding system**

The vibrating feed system on the left side of the hardware insertion machine is used for the automatic feeding of fastened riveting parts. It is an electric drive device that can hold and move 8 different types of fastening products. Connected to the vibrating plate are various types of tools so that the fastening rivets sent out of the hopper have their own directions of movement.

- Vibrating feeding controller-the amplitude or frequency of the vibrating plate is controlled by the vibrating feeding controller. The adjustment of amplitude and frequency is used to control the feeding rate and carry out the automatic feeding process.

### **Upper mold changing mechanism**


It consists of servo motor, linear module, slide cylinder, guide rail, buffer, material pipe, material pipe joint and carrier. Different types of PEM standard products correspond to different carrier platform tools. The upper mold change mechanism automatically switches to work with the corresponding feeding system and lower mold change mechanism.

### **Lower mold changing mechanism**

It is composed of servo motor, screw module, pen-shaped cylinder, guide rail, buffer, and lower mold. Different types of PEM standard products correspond to different lower mold tooling, and the lower mold change mechanism automatically switches to work with the corresponding feeding system and lower mold change mechanism.

## Binocular vision guidance system


The binocular vision system is mainly composed of two sets of camera lenses, light sources, and image processing industrial computers. It uses binocular vision technology to achieve precise positioning of workpieces and guide the XYZ mobile platform to move the product to the exact position where riveting is required.




NO.	PARTS NUMBER	DESCRIPTION
1	MDS100220001	Mobile ConsoleZ
2	MDS183720006	three-axis platform assembly
3	MDS012330002	80KN Electric Cylinder
4	MDS026430007	Structured light 3D camera
5	MDS180420020	upper mold change mechanism components
6	MDS181520007	lower mold change assembly
7	MDS180130154	Platform Electrical Cabinet Components
8	MDS184530054	Press Electrical Cabinet Assembly
9	15-40015	T series vibration plate assembly (MAS350)

**FIGURE 2-1**


**The components of PAT2400-E Hardware insertion machine**



NO.	PARTS NUMBER	DESCRIPTION	QTY
1	15-01708	FHCS, M3×0.5×10MM	2
2	PS210815	SAFETY SENSOR of LEFT, TURCK, NO	1
3	H-3892	SHSS, M3×0.5×4MM, BLACK OXIDE	3
4	PS210799	RAM ADAPTER, SAFETY SENSOR, 2nd GEN	1
5	10-00765	FERRULE, 18 GA, YELLOW	1
6	PS210801	BUSHING, 3/8" ID×1/2" OD	1
7	PS210815	SAFETY SENSOR of RIGHT, TURCK, NO	1
8	15-01450	CONNECTOR, 5 PIN, MALE	1
9	15-03209	FITTING, 3/8", BULKHEAD UNION	1
10	15-03208	HOSE, 3/8", AIR	1
<b>FIGURE 2-2</b> <b>Dual Safety Sensor Assembly (MDS101220002)</b>			



NO.	PARTS NUMBER	DESCRIPTION	QTY
1	MDS101230003	BODY, UPPER TOOL HOLDER, SAFETY SENSOR	1
2	15-03206	CONTINUITY SPRING, 1 3/4" UNIVERSAL	1
3	11-00016	CONTINUITY GUIDE PIN	1
4	H-3738	SHCS, M5 × 0.8 × 12MM, BLACK OXIDE	1
5	11-00241	THUMB SCREW CAP	1
6	11-00242	SHSS, M6 × 1.0 × 6, BLACK OXIDE	1
7	MDS012030040	Quick-change connector	1
8	15-01392	Spring pad	1
<b>FIGURE 2-3</b> <b>Upper Tool Holder Assembly(MDS101220005)</b>			




NO.	PARTS NUMBER	DESCRIPTION	QTY
1	MDS180430065	Upper module mounting base plate	1
2	MDS180430066	Linear module mounting plate	1
3	MDS180430067	Slider transition plate	1
4	MDS180430068	Air slide connection plate	1
5	MDS180430069	Air slide front mounting plate	1
6	MDS180430070	Module mounting base block	2
7	MDS180430071	Slide rail mounting plate	1
8	MDS180430072	Drag chain rolling groove	1
9	MDS180430073	Drag chain connection plate	2
10	MDS180430074	Drag chain moving mounting plate	1
11	MDS180430075	Guide rail slider mounting plate	2
12	MDS180430076	Guide rail mounting vertical plate	2
13	MDS180430078	Moving push plate	1
14	MDS183730012	Slide table module (SK8, S650)	1
15	MDS180430079	Slide table module upper connection plate	1
16	MDS012030167	Air Slide Table, 20×50	1
17	MDS012030168	Heavy load slide rail (MX28, S940)	1
18	MDS014630034	Heavy load slide rail (MX24, S160)	2
19	MDS011830082	FLOW CONTROL VALVE, METER OUT 6	2

20	MDS012930290	Straight rod locating pin 2.5-10	6
21	MDS012930291	Hexagon socket flat head bolt M3×8	6
22	PS191290	Straight rod locating pin	21
23	MDS012930292	Hexagon socket countersunk screw M5×12	16
24	MDS100430019	Mount, Tube Connector	8
25	MDS180430080	Drag chain mounting plate heightening pad	2
26	MDS180430081	Mounting Block, Backstop, Air Table	1
27	MDS180430040	LID, TUBE CONNECTOR, PA80SH	8
28	11-00238	SSS M5-0.8 x 6 LG	8
29	H-3681	Spring Plunger, #10 Steel	8
30	15-01709	FHSCS, M2 X 0.4 X 4MM, BLACK OXIDE	8
31	MDS012930178	PIN DOWEL 1/4" × 1/2", STEEL	16
32	MDS014630035	Drag chain	1
33	MDS180430082	Buffer connection block	2
34	MDS013130035	Hydraulic buffer	4
35	MDS180430083	Buffer rear connection plate	2
36	MDS180430084	Upper die set transition mounting plate	1
37	MDS180430085	Adjustment top plate	4
38	MDS180430086	Adjustment top plate pad	1
39	MDS012930293	Hexagonal head bolt M16×50	4
40	MDS180430088	GUARD, SHUTTLE, T1200, UPPER TOOL CHANGER ASSY	1
41	MDS180430087	Slider pad	1
42	MDS012930294	Locking pin Internal thread type	1
43	PS192916	Locking pin	22
44	MDS012930295	PIN DOWEL 6 × 12mm	7
45	8024048	Straight rod locating pin	8
46	MDS025330042	Integrated stepper servo motor	1

**FIGURE 2-4**

**Upper mold changing mechanism components (MDS180420018)**







NO.	PARTS NUMBER	DESCRIPTION	QYT
1	MDS181530043	Lower die change base base plate	1
2	MDS014630025	Slide rail + slider	2
3	MDS181530044	Guard top plate	2
4	MDS181530045	Lower die pad	1
5	MDS181530046	Buffer mounting plate	2
6	MDS181530047	Lifting side plate	1
7	MDS181530048	Protective side plate	1
8	MDS181530049	Cylinder fixing plate	1
9	MDS181530050	Groove photoelectric sensor sheet	1
10	MDS101630086	Cylinder fixing block	1
11	MDS101630087	Cylinder floating joint	1
12	MDS181530051	Front and rear adjustment top block	1
13	MDS101630089	Left and right adjustment top block	2
14	MDS181530052	Protective bottom plate	1

15	MDS181530053	Lifting seat	1
16	MDS013730021	Linear module	1
17	MDS015330006	100w servo motor, no brake, with keyway	1
18	MDS013330011	Coupling	1
19	MDS014630012	Linear rail	1
20	MDS041630558	Limiting block	4
21	MDS041630561	Slider seat	1
22	MDS041630622	Slider head	1
23	MDS041630576	Buffer mounting plate	1
24	PS180676	Speed control valve	2
25	MDS181530054	Linear positioning block	1
26	MDS041630566	Push block	9
27	MDS181530055	Bottom connecting plate	1
28	MDS181530056	Power block	1
29	PS171252	Photoelectric switch	3
30	MDS101630077	Sensor bracket	3
31	MDS041630671	Square die change insert block	1
32	MDS012030139	Cylinder	1
33	MDS041630670	Square die change insert seat	1
34	10-00214	Plastic Black Knob	2
35	MDS012030151	Cylinder	1
36	MDS100130058	Reinforced support	1
37	MDS101630056	Clamping top block	1
38	PS100653	Buffer	2
39	PS192456	Buffer	2
40	MDS181530057	Linear guide positioning plate	8
41	MDS181530058	Circular positioning plate	1
42	MDS181530059	Rising linear guide positioning plate	1
43	PS140034	POSITION PIN	12
44	MDS181530060	Module positioning plate	2
45	MDS181530061	SHCS, M12 MODIFIED	1
46	MDS181530062	PIN, LOWER TOOL HOLDER, T1200	1
47	8024048	Straight rod locating pin	12
48	PS192916	Locking pin	4
49	PS191290	Straight rod locating pin	6
50	MDS012930295	PIN DOWEL 6 × 12mm	4
51	PS191528	Speed regulating valve	2
52	PS191291	Straight rod locating pin	2
<b>FIGURE 2-5</b>			
<b>Lower mold assembly (MDS181520007)</b>			





NO.	PARTS NUMBER	DESCRIPTION	QTY
1	MDS100230003	T1200 control box	1
2	MDS100230004	monitor mounting plate	1
3	MDS100230005	adapter plate	1
4	PS160780	bracket	1
5	PS160781	casters	1
6	MDS026930094	54216 § KEL-U 10_6	1
7	MDS010230007	keyboard bracket	1
8	PS210477	3SB66JRR01 rotary reset emergency stop 1NC	1
9	PS210469	3SB66D3G10 green flat head with light 1NO	2
10	PS170066	panel mounted USB harness elbow type (1m)	1
11	PS210483	3SB69H18 25*18 label holder	2
<p align="center"><b>FIGURE 2-6</b></p> <p align="center"><b>Mobile console (MDS100220001)</b></p>			



NO.	PARTS NUMBER	DESCRIPTION	QTY
1	15-40015	ASSY, MAS 350 50 HZ	8
FIGURE 2-7			
Vibration feeding assembly			

## SECTION 3

### SAFETY SYSTEM OPERATION

---

#### **WARNINGS - To avoid injury:**



1. Always shut off the electrical power, and remove the power cord, before servicing this machine.
  2. Only authorized and trained personnel should maintain, repair, setup, or operate this equipment.
  3. Always use eye protection when operating or maintaining the pull riveting machine.
- 

#### **3.1 SYSTEM SAFETY FEATURES**

1. Turning off the electrical power, with either the “OFF” push-button, the ON/OFF switch, or pushing the E-Stop button, will cause the electric quick exhaust/supply valve to exhaust all air pressure in the rivet installation machine. **WITHOUT ANY CONTAINED PRESSURE, ALL PNEUMATIC MOTION STOPS.**
2. The electrical cabinet has been locked with a key to prevent unauthorized personnel from opening it.
3. Has a first-level password protection measure for safe access.


#### **3.2 SECURITY OF USAGE MODE**

The Safety System relies on the Dual Safety Sensor inside the Cylinder Ram Adapter, and position monitoring fulfilled by the Tooling Protection System (TPS). The Upper Tool Holder Retainer Screw secures the Upper Tool Holder to the Cylinder Rod. There is a black serrated knob on this Retainer Screw. It enables the Upper Tool Holder to move up on the Cylinder Ram Adapter .45 in/11.4 mm. To move up, the Upper Tool Holder must overcome the light force of the Continuity Spring.

If the Upper Tool Holder moves up .015 in/0.4 mm to 0.02 in/0.5 mm, the Safety Sensor will lose the target in the upper tool holder. Sensors should change state simultaneous otherwise the machine will bring the ram up.

Before each cycle the state of the 2 sensors in the ram adapter are monitored by the dedicated Safety Controller to ensure the upper tool holder is installed, and in released state.

In operation, when the Safety Sensors is actuated in Conductive Mode and a non-conductive material is between the Upper and Lower Tools, the Upper Tool Holder’s downward motion is reversed immediately and returns to its Up position. If the Safety Sensors is actuated and a conductive material is between the Upper and Lower Tools, the machine will continue the hardware insertion cycle if inside the TPS window. The machine will apply the set down force to the conductive material between the Upper and Lower Tools and then return to its Up position.



**Risk of crushing-A high risk crushing hazard is created by the Upper Tool and Lower Tooling.**



**Warning-Safety of the operator in non- conductive access operation must remain accessible only to trained and authorized personnel that are experienced in appropriate machinery operating conduct.**

**Do not operate this machine while wearing any metal objects (i.e., rings, watches, bracelets, etc.) that may come into contact with the Upper Tool, Lower Tool or work piece.**



**WARNING: Immediately upon receipt of your hardware insertion machine., establish a “Maintenance Code” for your supervisor/maintenance personnel only, as it is possible, however difficult, to operate the press without the standard safeguards in place in the Maintenance Mode. Only trained personnel should use the Maintenance Mode the PennEngineering® is not responsible for improper maintenance mode procedures which result in a loss of operation of the rivet installation machine. or operator safety.**

### 3.3 Safety System Tests

---

### Step 1: Safety Switch Test Procedure

---



**WARNING:** Experienced personnel must test the Safety System at the beginning of each work shift. See the Safety System Test in this section of this manual.

Depending on the ambient shop temperature, you may need to warm up your Hardware Insertion Machine before beginning any operations. To do this, turn it on and let it run for about ten minutes.

---

1. Turn the *Main Disconnect Switch* to the *On* position. The Main Disconnect Switch is located on the electrical cabinet to the right side of the machine.
2. Start the machine by pressing the On Switch on the touch screen control panel. The green light in the switch will be displayed and the motor will start. If the machine doesn't turn on, twist the Off/E-Stop Switch(s) clockwise until it pops out and try pressing the On Switch again. Using the touch screen controls, select the Conductive operation.



Except for the Down Footswitch and the *Off/E-Stop Switch*, all the other operating controls referred to in the rest of this procedure are on the Touchscreen Panel. The Touchscreen Panel is located on the front of the machine cover.

---

3. Set the Up Travel distance to 40% by touching the touch screen containing the Up Travel value and then choosing 40 from the entry screen. You can also use the +/- buttons.
4. Keep your hands away from the Tool Holder area. Use the Footswitches to lower or raise the Upper Tool Holder until it is about 4 in. /100 mm above the Lower Tool Holder. Remove your foot from the Footswitches and keep your feet away from it.
5. Carefully grasp the sides of the Upper Tool Holder and push it upwards. This upward movement should actuate the Safety Sensors and the Upper Tool Holder should move up. The movement will continue until the RAM reaches top of stroke. Remove your hand from the Upper Tool Holder as soon as the movement starts.
6. If the RAM moves up, the Safety System Sensors are operating.
7. If the Upper Tool Holder does not move up, the Safety System has failed!

Immediately turn the machine off by depressing the *E-Stop* button and turning the Main Disconnect Switch to the *Off* position. Contact your Supervisor. The machine's Main Disconnect Switch must be locked in the *Off* position until repairs are begun and follow Lock-out/Tag-out procedures. Do not operate this machine until qualified personnel have repaired the machine and the Safety System Sensors has been properly tested.



**WARNING:** There are two Steps in this testing procedure.  
Do not skip or ignore any of them!

---

## Step 2: Non-Conductive Mode Test

1. If you have just completed Step 2:
  - a) The machine is On and the green light in the On Switch is still illuminated. If not, return to Step 1 Safety Sensors test procedure and restart the machine by following Instruction in Steps 1 and 2.
  - b) The Conductive/Non-Conductive mode is displayed in the Conductive selection. Select Non-Conductive from the touchscreen display.
  - c) The machine's Force has been set to deliver 13KN. If this has been changed, repeat the instructions in Step 2, Instruction 4.
  - d) Verify the 1 in/25 mm Flat Anvils are installed in both the Upper and Lower Tool Holders.
2. Keep your hands away from the tooling area. Depress the Down Footswitch. The Upper Tool Holder should move down, the flat Anvils will contact, and the Upper Tool Holder should stop immediately. If this machine completes the above sequence correctly, go to Instruction 4.



**WARNING: When operating this Hardware Insertion Machine in the Non-Conductive Mode, be very careful! Do not depress the Down Footswitch a second time after the Upper Tool Holder has stopped on the down stroke with any part of your body near the tooling area.**

---

- a) If the machine does not complete the above sequence correctly, check the touch screen settings. If they are not correct, reset them and repeat the test. If the machine performs correctly, go to Instruction 3.
  - b) If the machine does not complete the above sequence correctly, there is a failure in the machine's control circuit and it must be corrected by qualified personnel. Immediately turning the machine Off by pressing the red Off Switch and turn the Main Disconnect Switch to the Off position. The machine's Main Disconnect Switch must be locked in the Off position until repairs are begun. Do not operate this machine until qualified personnel have repaired the machine and the Non-Conductive Mode has been properly tested.
3. Remove your foot from the Foot pedal switch box.
4. Carefully grasp the sides of the Upper Tool Holder and raise it until a positive stop position is reached. With a calibrated measuring instrument (Digital calipers are best), measure the vertical distance between the upper and lower Anvils. If this measurement is **at least a minimum of 1/4 in. /6 mm**, go to Instruction 6.
  - a) If this dimension is less than 1/4 in. /6 mm, **the Safety System has failed!**

Immediately turn the machine off by pressing the red Off Switch and turning the Main Disconnect Switch to the Off position. The machine's Main Disconnect Switch must be locked in the Off position until repairs are begun and follow Lock-out/Tag-out procedures. Do not operate this machine until qualified personnel have repaired the machine and the Non-Conductive Mode has been properly tested.
5. Next keep your hands away from the tooling area. Turn machine back "ON" and depress the Down Foot pedal switch a second time. The machine should exert the pre-set 13KN force to both upper and lower Anvils and then return to its Up position.



**If this machine completes the above sequence correctly, the test of the Safety Sensors and Safety System is complete and operating properly.**



**There are two Steps in this testing procedure.  
Do not skip or ignore any of them!**

---

## SECTION 4

### INSTALLATION OF HARDWARE INSERTION MACHINE

#### Transportation of the hardware insertion machine

- When using a forklift or pallet jack be sure that the forks are properly located between the fork guide tabs under the base of the hardware insertion machine. (See Fig 4-1)
- 



**WARNING: Unbalanced loading of the hardware insertion machine or sudden stops may lead to toppling of the hardware insertion machine.**

---

#### Locating the Hardware Insertion Machine

- Select a well-lit clean area with a (relatively) level floor. The floor must be able to support the weight of the Hardware Insertion machine.

#### Leveling the Rivet Installation Machine

- The hardware insertion machine should be leveled and stabilized after it has been located. This is done by adjusting the height of each footpad then locking each footpad in position by tightening a jam nut. This task requires two 36mm wrenches (See Fig 4-2). An adjustable wrench may also be used. Adjust the foot pad while reading the level at the tooling nut gate adapter. The universal escapement adapter must sit level for proper functioning of the feed systems.



#### Open Space Requirements

- PennEngineering® has no specific requirements for providing open space around the perimeter of the hardware insertion machine. However, be sure to comply with any national or regional safety codes that may dictate otherwise. We do recommend that you at least leave enough space around the hardware insertion machine so the various storage and maintenance enclosures can be opened fully and so the largest workpieces can be accommodated.


#### Original Installation Requirements

- After the final installation of the hardware insertion machine verify the continuity of the protective bonding circuit (TN-System) in accordance with EN 60204-1 Clause 18.2.2 standards.





**FIGURE 4-1**  
**Move Location Diagram**




**FIGURE 4-2**  
**Adjustable Footpad**

### **Recommended Air Supply Hook-Up Arrangement**

Proper air supply is very important to the performance and maintenance of the hardware insertion machine. Following these simple guidelines will ensure good machine performance.

- **Air Quality** - The quality of the air supply is very important. The air must be clean and dry. Moisture and debris will contaminate the oil and valve systems and lead to machine performance and maintenance problems.
- **Air Supply Flow** - Use a minimum 12mm diameter line and fittings from the compressed air source to the rivet installation machine. Shop pressure ranging between 6 to 7 bar (90 psi to 100 psi) is acceptable. Inadequate air flow will affect machine performance.
- **Air Consumption** - Air consumption in automatic mode is about 2.5 liters of compressed air per cycle. Average air consumption running at 6 insertions per minute is about 0.3 liters/sec at 1 atm.
- **Piping Installation** – Proper piping hookup will help achieve the above requirements. See Figure 4-3 on the next page.

- ◆ Connect to your supply line with a pipe pointing upwards that curves over and down. This arrangement will help prevent water and compressor oil from entering the machine.
- ◆ Connect to that drop with your supply fitting for a 12mm or larger hose.
- ◆ Continue the end of the drop to a drain valve. This will help collect additional water and oil and allow the system to be purged.
- ◆ If your factory air supply falls short of the above recommendations, an air reservoir tank of an appropriate size for your location can be used.
- ◆ An auxiliary filter/separator installed immediately outside the machine is recommended.



**FIGURE 4-3  
AIR SUPPLY**

## SECTION 5

### GENERAL FUNCTION DESCRIPTIONS

#### System Function:

The function of **PEMSERTER® PAT1200-E Hardware Insertion Machine** is to safely, quickly and consistently install riveting screws, nuts or studs for various types of plates. In order to achieve this function, the riveting machine adopts the following technologies and devices:

- Precise computer-controlled pressure riveting force and pressure riveting position.
- The automatic feeding system and Multi-Shuttle platform tooling can be selected according to the needs, and the product to be riveted can be positioned on the Vacuum Anvil (upper die), so that the operator can be released and can operate the workpiece freely.
- The system supports up to 8 different types of PEM fasteners mounted on one panel.
- Installation process monitoring, support curves, optional internal or external stored process curves.
- Automatic replacement of upper and lower punches.
- The binocular vision guidance system supports high-precision positioning and installation.

#### Setting up the Hardware Insertion Machine:

The following section of the manual describes the setup process in general. For details on setting up and operating the Hardware Insertion Machine see the appropriate section in the manual.

#### Step 1: Choice of tooling

The selection of tooling includes selecting suitable tooling for the delivered products and workpieces to be pressure riveted, including the tooling used for pressure riveting tooling and feeding control. The specific tooling type can be inquired through the website <https://www.haeger.com/ATW> or Haeger Wizard APP or consult the PEMSerter technical department.

#### Step 2: Select the Setup for the Tooling and Riveting Fastener on the Touchscreen.

Once the tooling is installed, the next step is to setup the rivet installation machine by using the touchscreen. The touchscreen setup is simple and can be done one of three ways.

- **Choice of tooling**-Choose tooling mode, riveting fastener size and types
- **Call pre-stored pressure riveting parameters**- Select from a previously programmed Job stored in the rivet installation machine.
- **Call the parameters of the last pressure riveting**-Call the same operating program that the riveting machine just ran last time, even after the shift is selected, the Hardware Insertion Machine will automatically set the operating variables and continue to perform security settings.
- **Manually set the pressure riveting parameters**-according to the needs of the product, manually set the pressure riveting parameters

#### Step 3: Safety Setup

The next step is very quick and simple but very important.

In the step of security setting, the Hardware Insertion machine needs to set the trigger position of the "safety trigger point" in the "Tooling Protection System (TPS)". The operator places the workpiece and the product to be riveted, but the riveting machine does not perform the actual operation of the product to be riveted. Step on the foot switch to make the hydraulic cylinder move slowly down. When the safety punch assembly touches the workpiece to be riveted, press the riveting product and trigger the safety punch assembly. At this time, the machine will record the position. This contact point is the correct trigger position and pressure position obtained by the riveting machine. At this point, the riveting machine is ready for pressure riveting operation.

### **Riveting Automatic Feed Functions:**

The automatic feeding function is completed by the vibrating feeding system and the storage system sending the products to be riveted into the multi-carrier platform tooling through the feeding tube. Take the following steps:

- The vibrating feed system moves the riveting product to the edge of the vibrating tray and transmits it to the Multi-Module.
- The direction of the riveting products is determined in the multi-module dislocation mechanism and sent to the Multi-Shuttle through the Tube. The riveting products to be riveted will be taken away by The Vacuum Anvil (Upper mold) through vacuum adsorption, and then be pressed into the workpiece. In the vibrating feeding system, the rest of the tightened riveting products with incorrect postures are blown out of the Multi-Module by compressed air and returned to the storage vibrating tray.

### **Pressure riveting process:**

- When the riveting product contacts the workpiece, the riveting machine judges the position of the "safety trigger point". Only when the safety trigger point is within a certain deviation range, can the pressure riveting process continue.
- If the safety trigger point is correct, apply pressure riveting force to the riveting product, and then the Anvil exits and returns to the origin.


## SECTION 6

### TOUCH-SCREEN CONTROLS

A programmable Automation Controller (PAC) controls the functions of the Device. The operator sends commands to the PAC and reads data from the PAC through a system of menus and information displayed on its touch screen. An operator need only touch the buttons displayed on the touch screen to make a selection.


The touch screen controls allow the operator to setup the Hardware Insertion Machine for operation, operate special functions and maintain and troubleshoot the machine.

#### 6.1 Main Screen



When system finish loading software 'Main Screen' will show.

[



]: Login In and Login Out

→To→6.1.1 Login Page

[Load]: First select a job in list and load current selected job

→To→6.1.2 Run Page

[Rename]: Select a job in list and rename current selected job

[Export]: Select a job in list and export a file that save in local.

[Import]: Choose a job file from local and import to system

[Delete]: Delete current selected job.


TIME:	NAME:	LEVEL:	JOB:
2021/7/23 10:32:50	ED	2	QUICKSTART

]: Load information show.



[ ]: Moto power on. When power on moto system will init and check all sensors.

→To→6.1.3 Power On Check Page




[ ]: Main air supply



[ ]: Language switch


→To→6.1.4 Language Switch Page

[JOB SELECT]: Load a job you have already saved in system.




[QUICK START]: Start to work with a new create job.

→To→6.1.5 Quick Start Page



[ ]: Remind you need to unlock estop and press 'Reset' button.

### 6.1.1 Login Page



The login page features a blue header bar with the 'PennEngineering' logo on the left and the word 'LOGIN' in white text on the right. Below the header, there are two white input fields: the first is labeled 'Name' and the second is labeled 'Password'. At the bottom of the form, there are two buttons: a purple button labeled 'OK' and a red button labeled 'Exit'.


[Name]: Login name

[Password]: Login password

[OK]: Enter

[Exit]: Exit page


### 6.1.2 Run Page



[Run]: Enter run mode

[Exit]: Load current job but not in run mode

### 6.1.4 Language Switch




Select the language you need.




### 6.1.5 Quick Start

Enter the task

Choose force control



Press mode set will only show press parameters:




[2]: Choose feed mode

FOOT switch / Outer switch / Screen Switch


FOOT switch: Trigger with foot switch。

Outer switch: Usually triggered by external communication control signals。




Press Position Page:

TPS can be set in different ranges, The same goes for pressure values, Pressure numerical tolerance



the page will show OK or NG:



## 6.2 MAINTAIN



[IO]

→To→6.2.1 IO Page

[SERVO]

→To→6.2.2 SERVO Page

[SIGNALS]

→To→6.2.3 SIGNAL Page

[LEVEL]

→To→6.2.4 LEVEL Page

[CALIBRATE]

→To→6.2.5 CALIBRATE Page

[CLEAN]

→To→6.2.6 CLEAN Page

[FACTORY]

→To→6.2.7 FACTORY Page

[EXIT]

→To→6.2.8 EXIT Page

## 6.2.1 IO

6.2.1 IO

MAINWINDOW | ID: 1000000000 | 1.1.0 | Runtime 10:34 | EVS ↓ | XY ← | Laser

TIME: NAME: Job Level 2 LEVEL: JOB:

AUTO

MAINTAIN

PARAMETER

LIFE TIME

DATA HISTORY

CURVE HISTORY

ASSESS (BETA)

ALARM

FEED

XY

HELP

POWER OFF

IO

SERVO

SIGNALS

LEVEL

CALIBRATE

CLEAN

FACTORY

COMMUNICATION

RECEIVE

WORD0	WORD1	WORD2 Customer
0	2560	0
0:Enable	0:Switch Station1	0
1:E-Stop	1:Switch Station2	0
2:Auto Once	2:Switch Station3	0
3:Feed Once	3:Switch Station4	0
4:Press No Feed	4:Recall Job1	0
5:Empty Cycle	5:Recall Job2	0
6:Clean Result	6:Recall Job3	0
7:Alarm Reset	7:Recall Job4	0
8:Station Switch	8:Light Curtain	0
9:Recall Job	9:Online change	0
10:Quit Run Mode	10:T Feed	0
11:Ram Down	11:Outer Bowl Control	0
12:Return Home	12:	0
13:Interrupt Press	13:	0
14:	14:	0
15:	15:	0

SEND

WORD0	WORD1	WORD2 RT Position
33024	6	12
0:Ready	0:Red Light	RT Position 0.12 mm
1:Pressing	1:Green Light	
2:Finish Press	2:Yellow Light	
3:Press Failed	3:Foot Down	
4:Feeding	4:Foot Up	
5:Finish Feed	5:	
6:Feed Failed	6:	
7:Alarm	7:	
8:EStop Status	8:	
9:Run Mode Status	9:	
10:At Station1	10:	
11:At Station2	11:	
12:At Station3	12:	
13:At Station4	13:	
14:Recall Job Succeed	14:	
15:Above Safety	7 SET	


Third party program startup

Auto Start ☐

DXE Path: E:\AT-ALL\2-1\61am\B\5-Block\B\5\bin\6\Debug\6\B\5\bin\6\B\5.exe


[IO]: Show Input and output in PLC modules

## 6.2.2 SERVO





[REAL TIME]: Show all the sensors in ServeHydraulic System



[]: Power on or power off the moto




[]: Set temporary force



[ ]: Monitor cylinder position and safety sensors status.



[ ]: Control ram up and ram down



[ ]: Set the speed of ram up and ram down

PS: Foot panel is enabled on this page. You can ram up and ram down with foot panel.

POSITION TEST		
<b>P1Home</b> P1Position 0 mm P1Speed 150 mm/s GO P1		<b>P3Safety Trigger</b> P3Position 0 mm P3Speed 150 mm/s Go P3
		SAVE

[P1Position]: The position of original

[P1Speed]: The Speed of going to P1

[P3Position]: The position of original


[P3Speed]: The Speed of going to P3

[GO P1] [GO P3]: Command to move to P1 or P3

[SAVE]: Save current parameters but won't save in job only use for temporary

[START DETECT]: Press this button then ram down to trigger the safety sensor. At now system will record the zero position. After this put a fastener under tooling. Repeat the operate. You will see the 'Result Length' on screen.

## 6.2.3 SIGNALS



### [Recive]

Bit	WORD0	
0	Enable	ON Enable outer signals
1	E-Stop	ON Estop triggered,OFF release Estop
2	Auto Once	OFF-ON,Rising signal trigger once(Auto control feed or not)
3	Feed Once	OFF-ON,Rising signal trigger feed once
4	Press No Feed	OFF-ON,Rising signal trigger press without feed
5	Empty Cycle	ON,Feed will stop working and safety detect will stop checking
6	Clean Result	OFF-ON,Rising signal trigger will clean the last press result
7	Alarm Reset	OFF-ON,Rising signal trigger will reset the alarm
8	Station Switch	OFF-ON,Rising signal trigger station switch(only muti stations)
9	Recall Job	OFF-ON,Rising signal trigger will recall the job
10	Quit Run Mode	OFF-ON,Rising signal trigger will quit the run screen
11		
12		
13		
14		
15		

Bit	WORD1	
0	Switch Station1	Switch1,When ON is working
1	Switch Station2	Switch2,When ON is working
2	Switch Station3	Switch3,When ON is working

3	Switch Station4	Switch4,When ON is working
4	Recall Job1	Recall Job1,When ON is working
5	Recall Job2	Recall Job2,When ON is working
6	Recall Job3	Recall Job3,When ON is working
7	Recall Job4	Recall Job4,When ON is working
8		
9		
10		
11		
12		
13		
14		
15		

[Send]


Bit	WORD0	
0	Ready	ON,No alarm and ram at home under run screen mode
1	Pressing	ON,Ram is under going down or booste
2	Finish Press	ON,Press finished until next loop or manual reset status
3	Press Failed	ON,Press failed until next loop or manual reset status
4	Feeding	ON,Under feeding
5	Finish Feed	ON,Finish feed until ram move or next feed loop
6	Feed Failed	ON,Failed feed until ram move or next feed loop
7	Alarm	ON,Alarm until everything ok
8	Estop Status	ON,Estop status
9	Run Mode Status	ON,Only under run screen
10	At Station1	ON,At station1
11	At Station2	ON,At station2
12	At Station3	ON,At station3
13	At Station4	ON,At station4
14	Recall Job Succeed	ON,Succeed recall job and signal will keep for 2s
15	Above Safety	ON,Ram above safety position(That can set by customer)
Bit	WORD1	
0	Red	ON,No alarm and ram at home under run screen mode
1	Green	ON,Ram is under going down or booste
2	Yellow	ON,Press finished until next loop or manual reset status
3	Foot Down	ON,Press failed until next loop or manual reset status
4	Foot Up	ON,Under feeding
5		
6		
7		

Bit	WORD3	
	RT Position	Data/100=mm

Bit	WORD4	
	RT Force	Data/100=kN



## 6.2.4 LEVEL MANAGE



[User Name]: Operator name


[User Password]: Operator password


[Confirm Password]: Operator password confirm

[SELECT LEVEL]:

- [SELECT LEVEL Top Level]: The top level allow modified everything
- [SELECT LEVEL Administrator]

## [6.2.5 LEVEL MANAGE]






[10 kN]: Set the loadcell range

Value	Offset	Limit	Sensor
0	0.022885561	386	0
1	0.08346033	416	0


Use 4-20ma analog control(The range force scale the 4-20ma)  
Sensoroffset between sensor and loadcell



[Start/Stop Calibration]: Start/Stop calibration


[Start/Stop Calibration]: Control start and stop calibrate from the set start force

6.2.6 CLEAN



You can choose the start and end dates of the clearance

6.2.7 Factory Set



Do not change anything ,Please contact the equipment manufacturer.

**Feed system: 1, standard Feed.**  
**2, Multiple Station Feed.**  
**3, Web Operation.**

## 6.9.2 ②Multiple Feed System.



Feeder Plate  
Setup and  
Turret Setup

Turret Numbers 1-8, Click on any turret number to switch automatically. The switching sequence is as follows: first, the current mold is automatically unloaded, and then the target mold is loaded.

You can incrementally or decrementally select turret numbers 1-8#. The corresponding feeder operation parameters can be independently set, including: feeder voltage, frequency, vibration time, air blow time, vacuum threshold, and other parameters. After setting, you can either "Send to Controller" or "Save Changes."

You can set the position where the puncher picks up the nails (the pre-lowering position).

The turret servo enables the "Motor Start" and "Homing Search" to initialize. It automatically switches to the default turret position after initialization

After initialization is complete, click the left and right arrow buttons to perform manual JOG teaching.

After entering the T1 reference position and spacing, other P positions can be automatically calculated.

You can also make fine adjustments to the data for each position. The adjustment rule is as follows: fine-tuning to the right increases the value, while fine-tuning to the left decreases the value. Remember to save the changes.

③Operation on page  
Including all the operations about XY platform, instead of press machine.

Press machine and vision system as "peripheral equipment".

JOG and teaching operation of XYZ axis

X axis parameter page

Y axis parameter page

Z axis parameter page

Base mold axis parameters page

Enter avoidance mode.

Z-axis reference calibration.

Matrix function Not available

"Point Jump" function.

Not available: Laser calibration

Platform initialization available.

Adjustment operations for moving drawing coordinates and compensation after taking photos can be performed.

Operations such as camera photography and reset alarms can be performed.

Press machine riveting operations can be performed.

Note: Ensure that the platform is in a safe position or at the riveting position before performing

After selecting 'Specify Hole Number,' click '② Go to Specified Hole Number Position,' and the platform can be moved.


After moving to the specified hole number and taking an OK photo, the platform can be shifted to the riveting position.

Before taking the photo, the platform needs to be raised to the photo-taking height.


⑥ Move to Hole Number Riveting Position: After visual compensation of the XY platform, it can be lowered!"

Manually specify a hole number to move directly to it. The corresponding 'Template Number' for the hole number will be displayed synchronously for camera photography use.


This mode function is disabled.




### 6.9.3 Homepage Display Overview



#### 6.9.4 X-Axis Operation Page Overview








### 6.9.5 Y-Axis Operation Page Overview




### 6.9.6 Z-Axis Operation Page Overview





### 6.9.7 Bottom Mold Operation Page Overview




### 6.9.8 Avoidance Mode Operation Page Overview

In Avoidance Mode, the motor can automatically move to a pre-set avoidance position to facilitate maintenance on the turret and other locations.

① : Activate Avoidance Mode.

② : Press the button three times consecutively to move to the avoidance position.

③ : After three presses, return to the position before avoidance.




In non-avoidance mode, you can also operate the single axis to the corresponding position and re-save to record the new position.

### 6.9.8 Jump Point Function Page Overview

Enter the 'Jump Point' screen to activate the jump point function. If 'Continuous Jump Point Mode' is not activated, the device will automatically turn off the jump point mode after completing one production cycle. If 'Continuous Jump Point Mode' is activated, the specified jump point mode will be executed in each subsequent cycle until manually canceled.

You can set a specified jump point code. For example, if jumping from point 5 to point 13, the device will start production from point 13 after completing production at point 4, skipping points 5 through 12.



## **SECTION 7**

### **PNEUMATIC SYSTEM**


#### **A. The initial pressure input of the pneumatic system**

- Your factory air supply should be clean, dry and, ideally, have a high flow capability. Airline feeds smaller than 12mm (1/2") will increase cycle time.
- Factory compressed air, set between 6 and 7 bar (90 to 100 psi), enters the system through a manually adjusted filter/regulator.

After flowing through the air filter pressure reducing valve, the air is connected to two valve islands through a  $\Phi 10$  pipe, and the valve plates on the valve islands control each pneumatic actuator (see pneumatic principle diagram 7-1).

#### **B. Air discharge**

Both sides of the pneumatic valve assembly plate are equipped with exhaust holes and are equipped with silencers. According to the action logic needs, the air is discharged from this.



NO.	PARTS NUMBER	DESCRIPTION	QTY
1	MDS011830001	Modular F.R.L Units	1
2	MDS011830012	Soft Start-up Valve	1
3	MDS011820010	Valve Island	2
4	PS200272	Feeding cylinder	8
5	MDS182020001	Vacuum generator assembly	1
6	MDS012030167	Slide cylinder	1
7	MDS012030151	Lifting cylinder	1
8	MDS012030139	Fixed cylinder	1

**FIGURE 7-1**  
**Pneumatic Schematic**

## SECTION 8

### ELECTRICAL SYSTEM



**WARNING:** Device uses high voltage electrical power. Only trained and authorized personnel may attempt to maintain, service, or repair its electrically powered subsystems, components or parts.

The electrical panel enclosure requires a special key to open. The purpose of this feature is to protect the machine from unauthorized persons tampering with the system and to help prevent unauthorized and untrained personnel from receiving an electrical shock. We suggest the key be kept by a manager/supervisor who will properly control its use.

Please refer to the drawing description for details.

#### **AC Power Distribution:**

The device is protected by a four-pole main circuit breaker. The orange line means there is still power after the power is off.

**The inline AC power entering the device is routed to the following 2 areas:**

- AC power supply
- Maintenance electricity.

#### **DC Power Distribution:**

- DC power supply from the main power supply for the programmable controller. Through different sub-circuits, it also supplies power to sensors and other input signals, touch screens, and programmable controllers that are used to control output drive cards for different load (output) switches.
- Light power.
- Motor, driver, Relay, Cylinder.

## ELECTRICAL/ELECTRONIC IO

**(Note: Most of the items mentioned below are illustrated in section two of this manual.)**

INPUT		OUTPUT	
1K2 EL1018 DI-8bit 10us		1K4 EL2008 DQ-8bit	
0	TouchSurface	0	MainAir
1	Conduction	1	
2	EmergencyStop	2	Emptyload S1
3		3	Slowdown S2
4	CrossSensor1	4	Booste S3
5	CrossSensor2	5	EStopValve S4
6		6	Reset Light
7		7	Laser
1K3 EL1008 DI-8bit		1K12 EL2008 DQ-8bit	
0	SafetySensor1	0	
1	SafetySensor2	1	
2	VacuumSensor	2	
3		3	Shuttle
4	FootSwitchDn	4	Blower
5	FootSwitchUp	5	Slide
6	LifeDetect	6	Vacuum
7		7	BowlControl
1K9 EL3062 0-10MA 12bit			
0	Pressure Sensor A		
1	Pressure Sensor B		
1K10 EL3152 4-20ma 16bit			
0	Temperature Sensor		
1			
1K12 EL5001 SSI			
0	LVDT		

## SECTION 9

### MAINTENANCE

The most important element of maintaining your PEMserter® rivet installation machine is to ensure that the compressed air supply is clean and dry. Do not use lubricated air. It is necessary to ensure the cleanness of the liquid drawing oil, do not open the filling port, and check the fastness of each pipe joint regularly.

Following the maintenance schedule below will also help maintain your hardware insertion machine in good running order.



**IMPORTANT:** Only qualified individuals should perform maintenance procedures. Unless otherwise specified, perform all maintenance with the hardware insertion machine disconnected from air and power. Follow safe practices and obey all local safety regulations.

---

#### Daily Inspection

<ul style="list-style-type: none"><li>• Safety punch system components.</li></ul>	<ul style="list-style-type: none"><li>• Perform safety system check procedures using “Testing the Safety System”.</li></ul>
<ul style="list-style-type: none"><li>• Upper Tool Holder.</li></ul>	<ul style="list-style-type: none"><li>• Replace Risk of Crushing label if peeling or damaged.</li></ul>
<ul style="list-style-type: none"><li>• Check the Multi-Module.</li></ul>	<ul style="list-style-type: none"><li>• Check whether there are impurities in the Multi-Module of the vibrating feeding system and whether it needs cleaning.</li></ul>
<ul style="list-style-type: none"><li>• Check air pressure.</li></ul>	<ul style="list-style-type: none"><li>• Check inlet pressure of 0.6MPa.</li></ul>
<ul style="list-style-type: none"><li>• Check the sound of the device working.</li></ul>	<ul style="list-style-type: none"><li>• Check the device is running without sound.</li></ul>



## Weekly Inspection

<ul style="list-style-type: none"><li>• Check the Multi-Shuttle platform and its cylinder</li></ul>	<ul style="list-style-type: none"><li>• Correct and test the concentricity of the Multi-Shuttle platform with the upper and lower molds.</li><li>• Check the smoothness of the sliding table cylinder.</li></ul>
---	--

## Monthly Inspection

<ul style="list-style-type: none"><li>• Upper Tool Holder</li></ul>	<ul style="list-style-type: none"><li>• Upper Tool Holder.</li><li>• Small amount of lithium grease (white) between upper tool holder &amp; cylinder rod.</li></ul>
---	---

**Six months Inspection**

<ul style="list-style-type: none"><li>• Shuttle Jaws of Multi-Shuttle.</li></ul>	<ul style="list-style-type: none"><li>• Inspect Springs and change out if they appear weak.</li></ul>
<ul style="list-style-type: none"><li>• Flight Tubes</li></ul>	<ul style="list-style-type: none"><li>• Inspect and change out if damaged.</li></ul>
<ul style="list-style-type: none"><li>• Grease the cylinder</li></ul>	<ul style="list-style-type: none"><li>• Inject a certain amount of Shell Gadus S2 V2202 grease into the cylinder.</li></ul>

### Annual Maintenance

<ul style="list-style-type: none"><li>• Clean Air Valves (optional)</li></ul>	<ul style="list-style-type: none"><li>• If contaminant build up occurs, clean the pneumatic valves annually.</li><li>• If wear is serious, replace the pneumatic valve.</li></ul>
<ul style="list-style-type: none"><li>• Check the condition of the cylinder</li></ul>	<ul style="list-style-type: none"><li>• Make sure the connections are tight and the wires are not frayed or broken, which could affect the proper functioning of the electric cylinder.</li></ul>

### 3 Year Maintenance

<ul style="list-style-type: none"><li>• Check PAC status and clean the PAC.</li><li>• Replace the button battery of touch screen PC.</li></ul>	<ul style="list-style-type: none"><li>• Checking the PAC and replacing the button battery of touch screen PC can avoid an accidental loss of the program. When clean the PAC and replace the button battery of touch screen PC, the machine should be powered off.</li></ul>
--	--

## SECTION 10

### TROUBLESHOOTING

**Note:** If an internal PAC problem should develop, call a PennEngineering® service technician, please call +86 (512) 5726-9310.

SYMPTOMS	DIAGNOSTICS & PROBABLE CAUSE(S)	PROBABLE SOLUTION(S)
<b>A. Whole System Malfunctions</b>		
1. The machine will not start. (OFF light not lit) The machine will not start. (ON light is lit)	a. Electrical disconnect turned off. b. No power to the machine. c. DC Power Supply failure.	a. Turn on the power. b. Check main fuses. c. Check DC Power supply, replace if faulty.
	a. OFF button is “open”. b. ON button is not closing. c. MCR (Main Control Relay) system failure.	a. Check button, replace if faulty. b. Check the wiring continuity, replace if faulty.
2. The machine will not cycle.	a. Safety sensor inputs are on. b. Start button is not making the proper PAC input.	a. Check the wiring of the sensor b. Check the wiring of the start button. If it is faulty, it should be replaced.

SYMPTOMS	DIAGNOSTICS & PROBABLE CAUSE(S)	PROBABLE SOLUTION(S)
<b>B. Electrical/Electronic Malfunctions</b>		
1. The touch screen will not work but the power button is lit.	a. The circuit breaker is open.	a. Analyze and repair the touch screen related circuitry then replace the fuse. b. Replace the touch screen if faulty.
2. The lights of the programmable controller are not on.	a. Check to see if the PAC power supply is receiving 24 volts. b. Check the fuse in the PAC power supply. c. Check to see if the PAC power supply has failed.	a. If not receiving power check breaker. b. Replace the breaker in the power supply. c. Replace the power supply.
3. The sensors are not functioning.	a. Check to see if breaker is open. b. Check all sensors to see if one has a "short." c. Check the DC input module.	a. If open, investigate the circuitry and replace fuse three. b. Repair the "short" problem and/or replace the sensor. c. If faulty, replace the DC input module.
4. The DC power supply is not functioning.	a. Check the main power breaker. b. Check for line voltage at the supply terminals.	a. Replace if blown. b. Check the wiring between the power inlet module and the supply. c. Replace the power supply.
5. The machine will not power-up.	a. Check to see if there is incoming power. b. Check to see if the main disconnect is shut off. c. Check MCR's wiring.	a. Provide the power. b. Turn to the ON position.
7. The machine will not power-down.	a. Check to see if the OFF button is faulty. b. check MCR's /wiring.	a. Replace if faulty.
8. There is no voltage at the solenoid valve.	a. Check for a shorted coil. b. Check the related PAC output voltage.	a. Repair or replace. b. Replace the output card if faulty.

SYMPTOMS	DIAGNOSTICS & PROBABLE CAUSE(S)	PROBABLE SOLUTION(S)
<b>C. Pneumatic System Malfunctions</b>		
1. The air pressure does not reach the set value.	a. Check for leaks.	a. Repair any leaks.
<b>D. Tooling Malfunctions</b>		
1. The Multi-Module is jammed.	a. A fastener is jammed.	a. Clear the fastener.
2. Fastening and riveting products are not normally sucked out from the Multi-Shuttle tooling by the vacuum pressure rod.	a. Multi-Shuttle tooling uncalibrated center.	a. Recalibrate Multi-Shuttle tooling.
3. The long lengths of studs are jamming in the tube.	a. Bends in tube are too tight.	a. Redress tube to bend toward the frame and then through the tube clips on the frame.
<b>E. Vibratory Bowl System Malfunction</b>		
The bowl does not vibrate.	a. Check whether the circuit breaker of the vibrating plate drive controller is intact. b. Check whether the output signal light of the programmable controller is on. c. Check whether the internal circuit of the feeding drive controller is normal.	a. Check whether the solenoid coils at both ends are short-circuited. If there is a short-circuit, replace the coil, and then replace the circuit breaker of the feeding drive controller. b. If a failure occurs, replace and reprogram the programmable controller. c. If necessary, parts or controllers should be replaced.



## SECTION 11 SPARE PARTS

PART DESCRIPTION	PFT PART NUMBER	QTY	MANUFACTURER	MANUFACTURER'S PART NUMBER
<b>Level One Spare Parts</b> (Maintain this minimum inventory of parts for standard mechanical wear items on the machine.)				
AC208-500V To AC220-4KVA Transformer	MDS025730006	1	Murr	86156
2KWServo driver	MDS025330063	1	OMRON	R88D-1SN20F-ECT
2KWServo motor	MDS015330003	1	OMRON	R88M_1L2K030C_S2- AC400
750WServo driver	MDS025330062	1	OMRON	R88D-1SN08H-ECT
100WServo driver	MDS025330060	1	OMRON	R88D-1SN01H-ECT
PAC_Codesys	MDS024830012	1	HCFA	Q1-1200-D3
structured light-3D- Camer	MDS026430007	1	Imalligent	VRH5-5050
industrial computer	MDS025020001	1	Imalligent	BP1000
1KWServo driver	MDS025330126	1	OMRON	R88D-1SN10H-ECT
1KWServo motor	MDS025330140	1	OMRON	R88M-1M1K020T-S2

PART DESCRIPTION	PFT PART NUMBER	QTY	MANUFACTURER	MANUFACTURER'S PART NUMBER
<b>Level Two Spare Parts</b> (Add these items to the spare parts in inventory when no downtime can be tolerated.)				
relay WITH TEST	PS193070	1	Phoenix	1032526
relay base	PS193071	1	Phoenix	2908341
Key switch	PS180473	1	Schneider	XB2BG41C
Rotary reset emergency stop	PS210477	1	SIEMENS	3SB6160-1HB20- 1CA0
touchpoint - 1NC	PS210479	1	SIEMENS	3SB66400-1AA10- 1CA0
Safety relay 3NO 1NC	PS180602	1	Phoenix	1046360
main switch 40A	MDS02603009 9	1	Schneider	VCF2
Transformer	MDS02573000 8	1	GBL	QZB- 3KVA/3AC380- 3AC220
Tricolor light	MDS02613003 0	1	SIEMENS	8WU4624-5GH06
Panel socket	PS201149	1	murr	4000-68713- 8080001

AC208-500V To AC220-4KVA Transformer	MDS02573000 6	1	murr	86156
2KWServo driver	MDS02533006 3	1	OMRON	R88D-1SN20F-ECT
2KWServo motor	MDS01533000 3	1	OMRON	R88M_1L2K030C_S2 -AC400
1KWServo driver	MDS02533012 6	1	OMRON	R88D-1SN10H-ECT
1KWServo motor	MDS02533014 0	1	OMRON	R88M-1M1K020T- S2/Omron-AC200
2KW Flexible power line	MDS02533012 3	1	OMRON	R88A-CA1C010SF
1-3KW Flexible coded cable	MDS02533012 4	1	OMRON	R88A-CR1B010NF
750W-Flexible power line-10M	MDS02533006 8	1	OMRON	R88A-CA1A010SF
750W-Flexible coded cable-10M	MDS02533006 5	1	OMRON	R88A-CR1A010CF
750W-Flexible break cable-10M	MDS02533007 0	1	OMRON	R88A-CA1A010BF
750WServo driver	MDS02533006 2	1	OMRON	R88D-1SN08H-ECT
100WServo driver	MDS02533006 0	1	OMRON	R88D-1SN01H-ECT
Servo motor-750W break , keyway	MDS02533009 7	1	OMRON	R88M-1M75030T- BS2
Servo motor-100W, No break , keyway	MDS01533000 6	1	OMRON	R88M-1M10030H- S2
Flexible power line- 10M	MDS02533012 7	1	OMRON	R88A-CA1B010SF
Breaker -10A	PS211058	1	SIEMENS	5SY6310-7CC
filter	PS210329	1	SIEMENS	6SL3203-0BB21- BVA1
Electronic circuit Breaker -10A	PS181022	1	Phoenix	2906032
Green button	PS202215	1	SIEMENS	3SB6163-0DB40- 1BA0
structured light-3D- Communication line- 10M	MDS02703002 1	1	Imelligent	Ethernet Cable 10M
structured light-3D- POWER line-10M	MDS02733007 9	1	Imelligent	HTVR-I/O Cable
structured light-3D- Camer	MDS02643000 7	1	Imelligent	VRH5-5050
industrial computer	MDS02502000 1	1	Imelligent	BP1000

PAC_Codesys	MDS024830012	1	HCFA	Q1-1200-D3
Three-phase 240W power supply	MDS025630004	1	Meanwell	TDR-240-24
Main switch guide rod-330mm-25A panel-KCD1PZC	PS210579		Schneider	VCCD0C
22mmBuzzer red light	MDS026130004	1	Phoenix	1108842
Blue button with light 1N0	MDS026130002	1	SIEMENS	3SB6163-0DB50-1BA0
Green button with light 1N0	PS210469	1	SIEMENS	3SB6163-0DB40-1BA0
Breaker 2P_4A	PS201775	1	SIEMENS	5SY6204-7CC
Breaker 3P_10A	PS211058	1	SIEMENS	5SY6310-7CC
Breaker 3P_16A	PS211059	1	SIEMENS	5SY6316-7CC
Breaker 1P_10A	PS210495	1	SIEMENS	5SY6104-7CC
Breaker 1P_4A	MDS026030001	1	SIEMENS	5SY6106-7CC
EtherCat coupler	MDS024830013	1	ODOT	CN-8033
16 INPUT PNP	MDS024830014	1	ODOT	CT-121F
16DO-OUTPUT PNP	MDS024830015	1	ODOT	CT-222F
4-20ma 15bit	MDS024830016	1	ODOT	CT-3238
Solid State Relay	PS190445	1	Phoenix	RIF-0-OPT-24DC
M12_5Pin_A-code-Female10 米	MDS026930067	1	MURR	RKT_5-228/10M
switch module 8port	MDS025930004	1	Phoenix	1085256
DC 480W power supply	PS201751		Phoenix	ESSENTIAL-PS/1AC/24DC/480W/EE
4P-40A Breaker	MDS026030100		SIEMENS	5SY6440-7CC
2P-10A Breaker	MDS026030052		SIEMENS	5SY6210-7CC
2P Breaker 4A	PS201775		SIEMENS	5SY6204-7CC
M12 D-code M12-RJ45 10 米	PS210504		MURR	0985 342 104/10

## **Appendix**

### **Electrical Schematic**

XYP

IEC\_tp1001

“已授权”

印章

2023/10/11


Inv. №	Orig.	签名和日期	Ers. inv. №	Inv. №	Dupl.	签名和日期

0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---

右侧电箱B镜像开孔

左A侧电箱右视图 (电箱面板) 左A侧电箱后视图 (电箱面板)

### 右B侧电箱右视图（电箱面板）




42147

54241




4									
			日期	2024/7/10	EPLAN	T1200平台分体配电箱开孔视图			=
			校对	LEAN					+
			审核		XYP				
修改	日期	姓名	原拟项目		移植人				
							IEC_tp1001	页数	
								01	A/4











修





















Page 81 of 140



20		Phoenix#3210567 PS201953		Phoenix#3211634 PS201954		PS190163 Phoenix#3030213		22	
		日期 2024/7/15		EPLAN		Servo DC24-0			
		校对 LEAN							
		审核		XYP				IEC_tp1001	
修改		日期		姓名		原始项目		页数 21	
				替换		替换人		页 16 / 49	





Phoenix#3210567  
PS201953

Phoenix#3211634  
PS201954

PS190163  
Phoenix#3030213




22 24

			日期	2024/8/13	EPLAN	DC2_0V COM		=	
			校对	LEAN					
			审核		XYP			+	
修改	日期	姓名	原始项目	替换	替换人		IEC_tp1001		页数 23
									页 18 / 49









24

26


			日期	2024/7/8	EPLAN		PAC_LIST-左侧		=
			校对	LEAN					+
			审核		XYP				
修改	日期	姓名	原始项目		替换	替换人		IEC_tp1001	页数 25 页 20/49












28 30




			日期	2024/7/10	EPLAN		PLC_HC-左侧		=
			校对	LEAN					+
			审核		XYP			IEC_tp1001	页数 29
修改	日期	姓名	原始项目		替换	替换人			页 24 / 49

风扇




			日期	2024/7/10	EPLAN		FANS		=
			校对	LEAN					+
			审核		XYP				
修改	日期	姓名	原始项目		替换	替换人		IEC_tp1001	页数 30 页 25 / 49







Page 95 of 140





34

36


			日期	2024/7/8	EPLAN	DC5																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																										
--	--	--	----	----------	-------	-----	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--







			日期	2024/7/8	EPLAN		JoyStick			=
			校对	LEAN						+
			审核		XYP					
修改	日期	姓名	原始项目	替换	替换人			IEC_tp1001	页数 41	
									页 36 / 49	




41

		日期	2024/7/10	EPLAN	Cylinder_Sensor左侧			=
		校对	LEAN					+
		审核		XYP				
修改	日期	姓名	原始项目	替换	替换人			IEC_tp1001
							页数	42
							页	37 / 49

43






46

48

		日期	2024/8/13	EPLAN		IK4_CT121F 2载具板IO-左侧		
		校对	LEAN					
		审核		XYP				
修改	日期	姓名	原始项目	替换	替换人		IEC_tp1001	页数 47 页 42 / 49


0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---




接线图

PROFIBUS DP, EtherCAT, PROFINET,


Ethernet POWERLINK, PROFIsafe



-Air-Island2




47			日期	2024/7/10	EPLAN		Z轴_SS5Y5, 6位阀岛-右侧			49
			校对	LEAN						
			审核		XYP					
修改	日期	姓名	原始项目	替换	替换人			IEC_tp1001	页数	48
									页	43 / 49

















51		54 T2400端子台布局图									
		日期	2024/7/9	EPLAN							
		校对	LEAN								
		审核		XYP							
修改	日期	姓名	原始项目	替换	替换人						



















	日期	2024/8/13	E68	= E68 + AE
	设计	EH		后一页: 13
	审核		COMMON_INPUT	当前页: 12
修改	批准			最大页: 33














































		日期	2024/8/13	E68	SH_F1_SENSORS	= E68 + AE
		设计	EH			
		审核				
修改		批准				
						后一页: 34
						当前页:32 最大页: 33







	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
A	CF_CONNECT															
B																
C	<div>PS193066 PXC. 1411325 PS210401 PXC. 1182093 -CONNECT_5M_A</div> <div><div>F1C_FEMALE PXC. 1424228 PS191684</div><div>F2C_FEMALE PXC. 1424228 PS191684</div><div>F3C_FEMALE PXC. 1424228 PS191684</div><div>F4C_FEMALE PXC. 1424228 PS191684</div></div>					<div>PS180571 PXC. 1411440 PS180570 PXC. 1411461 PS210400 PXC. 1182090 -CONNECT_5M_B</div> <div><div>M1C_MALE PXC. 1424246 PS191683</div><div>M2C_MALE PXC. 1424246 PS191683</div><div>M3C_MALE PXC. 1424246 PS191683</div><div>M4C_MALE PXC. 1424246 PS191683</div></div>					<div>PS180571 1411440</div> <div>PS180570 1411461</div> <div>PS210400 1182090</div> <div>PS191683 1424246</div>					
D	<div>PS193066 1411325</div> <div></div>										<div>PS180571 1411440</div> <div></div>					
E	<div>PS210401 1182093</div> <div></div>										<div>PS180570 1411461</div> <div></div>					
F																
G	<div>PS191684 1424228</div> <div></div>										<div>PS210400 1182090</div> <div></div>					
H																
I											<div>PS191683 1424246</div> <div></div>					
J																
K																

	日期	2024/8/13	E68	= E68 + AE
	设计	EH		后一页: 39
	审核		CF_CONNECT	当前页: 37
修改	批准			最大页: 33



